



FITTING INSTRUCTIONS FOR


Battery Fuse Bracket

SKU

KS0682

COMPATIBILITY

Toyota LandCruiser LC200



Included contents

| QTY | COMPONENT | QTY | COMPONENT |
|-----|----------------------|-----|-------------------------------|
| 1 | Battery Fuse Bracket | 8 | M4 x 16 Socket Head Cap Screw |
| 8 | M4 Nyloc Nut | 8 | M4 x 9 x 0.8 DIN Flat Washer |



Time

The bracket takes just a few minutes, but wiring time is dependent on your setup.

For further information contact KAON on **07 3180 1470** or info@kaon.com.au

Let's get to work.

Preparation

1. First you'll need to uninstall the plastic trim cowl under the bonnet, at the front of the engine bay. This can be removed by pushing down on the trim clip buttons. Set the trim piece and buttons to one side.
2. Ensure that all surfaces are clean, and free of dust and debris.
3. If you have dual batteries, decide which side you're going to install the bracket to. Remove the two nuts holding the factory battery clamp in place and set to one side.






Installation

4. Test fit the Battery Fuse Bracket over the factory clamp. You will need to ensure you have sufficient clearance to the terminal cables and any fuse blocks. Depending on your setup, this may require reconfiguring the cables slightly, so they run into the terminals from the sides.
5. You'll want to work out what fuses you're mounting, and in what configuration. Our bracket has holes for most common fuses. But should you find you want to run something else, it's made from aluminium so you can easily drill additional holes.

We've also provided enough stainless steel mounting hardware to suit most applications, with eight M4 bolts, washers and nyloc nuts.

6. With all the fuses mounted, place the bracket **over** the factory battery clamp, and secure in place using the two factory nuts.
7. Confirm the position of the bracket and that it has sufficient clearance to the terminals. Gently close the bonnet to confirm sufficient clearance to the underside.
8. With all clearances confirmed, tighten the factory nuts.
9. Reinstall the plastic trim cowl by inserting the trim clip buttons into their recesses and pushing down until secured. Be careful not to fully depress the clip, as this will disengage it.
10. That's it, the bracket install is done! But your wiring job has just begun. Our bracket has two ramps on each side with slots for cable management with zip-ties, to help make this job easier.



Bolt Torque

| | | | | | |
|--------------------|------|------|-------|-------|-------|
| DIAMETER (mm) | 5mm | 6mm | 8mm | 10mm | 12mm |
| NEWTON-METRES (Nm) | 5 Nm | 9 Nm | 22 Nm | 44 Nm | 77 Nm |



Local Knowledge & Assistance

We know half the fun of building your dream 4x4 is getting your hands dirty. But we also know that sometimes, things don't go to plan. If in the pursuit to build the ultimate setup you find yourself off-track, we're here to help you get unstuck.

For further information call 07 3180 1470 or email info@kaon.com.au

Disclaimer: The products sold by KAON should not be modified, and are for use only on the vehicles specifically stated. KAON will not be liable for any damages arising out of the use or misuse of its products. It is the customers responsibility to ensure the products are safely and properly used and installed. KAON consistently seeks to improve its products and reserves the right to make changes to any product.